



MAXIMIZER™

LAUNDRY GUIDE

GETTING STARTED:

1.



CLEAN the laundry machines daily, before the first use.

2.



SEPARATE Rubbermaid Mops from other textiles.

3.



WASH Rubbermaid Mops in the Rubbermaid Mesh Laundry Net to manage inventory.

4.




DETERMINE detergent and maximum load size using chart below.*

DETERGENT AND LOAD SIZE BY MACHINE

WASHER SIZE	MAX VOLUME	DETERGENT LOAD**	STRING MOPS PER LOAD
60 LB. / 27.2 KG	71.8 GAL. / 272L	1.5 OZ. / 44.4ML	30
80 LB. / 37 KG	97.8 GAL. / 370L	2.0 OZ. / 59.2ML	40
100 LB. / 46 KG	121.3 GAL. / 1014L	2.5 OZ. / 73.9ML	50
140 LB. / 64.3 KG	169.6 GAL. / 642L	3.5 OZ. / 103.5ML	70

LAUNDRY INSTRUCTIONS:



COMMERCIAL WASHING: HOT WATER METHOD

- Wash in hot water (160°F/71°C) for 25 minutes¹
- Use Detergent and Load Size By Machine Guide to select appropriate capacity setting



COMMERCIAL WASHING: COLD WATER METHOD

- Wash in cold water
- Use Detergent and Load Size By Machine Guide to select appropriate capacity setting



COMMERCIAL DRYING

- Dry mops on low heat (130°F/54°C) setting
- Allow string mops to come to room temperature in open air
- Store dry mops in clean Rubbermaid Cube Truck



REQUIRED CARE

- Do not store Rubbermaid Mops in a washing machine overnight
- Do not use fabric softener in the wash cycle
- Do not use dryer sheets in the dry cycle
- Do not wash Rubbermaid Mops with other textiles

TRANSPORTATION:



CONTAMINATED TEXTILES

- Use Personal Protective Equipment (PPE) before transferring soiled textiles into laundry machine
- Handle contaminated textiles carefully to avoid agitation
- Sort soiled Rubbermaid Mops from other textiles at the point of contamination using the Rubbermaid Mesh Laundry Net
- Transport soiled textiles to the laundry with black Rubbermaid Cube Truck with Cover



CLEAN TEXTILES

- Remove dry textiles from the dryer immediately
- Transport clean textiles in a properly cleaned blue Rubbermaid Cube Truck with Cover or Rubbermaid X-Cart with Cover
- Store clean textiles for only short periods of time. Wrap clean textiles for long-term storage
- Distribute textiles back into facility

OR



*Machine settings can be established by chemical provider.

**Represents 1/2 the average manufacturer's detergent recommendation. Using full amount of detergent can result in hazy floors.

Always follow the protocol as directed by your facility manager.

¹Per CDC Guidelines for healthcare facilities.